

Cosmopolite - Sound Specifications

Units	Equipment
FOH Speakers	
8	b&b C7 Top Speakers - high/Mid
8	d&b C7 Sub Speakers - Low
2	B2 Sub Speakers - Low
4	d&b MAX Speakers - Front fill
FOH Speakers AMP	
5	d&b D12 - Stereo amps for the C7 and B2 speakers
2	d&b E-pac - amps for the front fills
FOH Mixing Console	
1	Soundcraft MH4
40	Mono channels
4	Stereo channels - used for the effect processor returns
8	Groups
12	AUX - 6 of them used for monitors, 4 of them used for effects and 2 of them are available
8	VCA
8	Matrix
<i>This is a default configuration of the console it the COSMOPOLITE VENUE.</i>	
<i>The console can be configured differently depending of the show.</i>	
<i>For more information check soundcraft home page: www.soundcraft.com</i>	
FOH EQ Rack	
1	Klark Teknikk - 31 band stereo GEQ for the main
3	DBX - 31 band stereo GEQ for the monitors
FOH FX Rack	
1	Bricasti M7 - mono send and stereo return
1	Lexicon PCM92 - mono send and stereo return
1	Yamaha SPX - mono send and stereo return
1	TC D-Two - mono send and stereo return
4	DBX 160A - giving 4 channels of compression
1	Klark Teknik DN504 - giving 4 channels of compression
2	Drawmer DS201 expanders/gates - giving 4 channels of expand/gate
1	Stanton C.402 - CD player
Monitor Speakers	
10	d&b MAX
1	JBL EON - active monitors
Monitor Speakers AMP	
3	CROWN XLS 802 - stereo amps 500W@80hm/800W@4ohm
Stage Box A	
32	Inputs - patched to the console
10	Returns - 2 of them for main and 6 for monitors

Stage Box B	
16	Inputs
8	Returns

Cosmopolite

— SCENE OSLO —

Updated: January 2020